



Before removing old fluorescent or LED lamps, shut off power to the light.


* Retrofitting should be done by a qualified installer who will follow all relevant building and electrical codes.



Retrofitting **TROFFERS**




Remove lens.



Remove lamps.




Remove ballast cover.




Disconnect power wires and carefully remove old ballast and sockets.




Housing is ready for the installation of the
BLUDRiVe™ BD35.



Splice building power through the disconnect provided.




Choose between 750mA (35W), 600mA (28W), or 450mA (21W) using the power settings switch.



Overview of BLU DRiVe™ features.

Retrofitting **TROFFERS**

Opposite end of cable plugs into BB (1) port




24" cable end and antenna

Plug 24 inch BLU BaRS™ cable into the BLU DRiVe™ BB (1) port and leave opposite end out of ballast cover for connection to BLU BaR™.
Leave 3 inches of Antenna outside of ballast cover.



BB cable and Antenna are left outside of ballast cover

You are now ready to connect the first BLU BaR™.



Plug 15 inch cable provided into one end of first BLU BaR™ then plug opposite end into the 24 inch cable that is left outside of the ballast cover.
Center BLU BaR™ on the side of fixture using magnets provided.

Second BLU BaR™




Tuck excess connector cable into the housing and leave 3 inches of antenna out

Plug 15 inch cable provided into one end of first BLU BaR™ then center BLU BaR™ on the other side of fixture using magnets provided. use a portable drill with Philips head to drill one tek screw (provided with BLU BaRS™) into both sides of each BLU BaR™.




Retrofitting **TROFFERS**



Clean and replace lens. You are now ready to energize! The BLU BaRS™ will express the default color and power settings.



Retrofitting **TROFFERS**



After energizing you may connect and program using the SMART BLU™ App. See www.smartblu.com for more information.

Download the SMART BLU™ App





Retrofitting **TROFFERS**




Using the SMART BLU™ app, you may adjust color from 2700K...

Download the SMART BLU™ App



BLUBaRS™
Retrofit System

Retrofitting **TROFFERS**



...to 6500K and any color in between.


Download the SMART BLU™ App



SMART
BLU™



Retrofitting **TROFFERS**




Easily dim your BLU BaRS™

Download the SMART BLU™ App





Retrofitting **TROFFERS**



You can dim your BLU BaRS™ from 100% down to 1% and anywhere in between.

Download the SMART BLU™ App

